



Equalizer Systems Operation on Conquest/Gulf Stream

On Conquest motorhomes the two front hydraulic jacks will operate in tandem by pushing either the left front or right front buttons on the keypad. The jacks will operate in tandem, but work independently by transferring fluid from one side to the other. The left rear and right rear jacklegs are used to level the coach from side to side.

For example, if the coach were to be parked on a left to right decline (the left side sitting higher than the right), the right rear jackleg can be extended to overcome the slope. When doing so, there will be a transfer of fluid from the left front jack to the right front jack allowing the coach to level and stabilize. The front and rear jacks may be operated to level the coach from front to back.